



DEMOLITION/GENERAL NOTES

- 1 Remove exist. expansion joint assembly & corridor floor & walls. Replace with new finish assembly, TYFE C10-19-94 ARCHITECTURAL ART MANUFACTURING, INC. OR EQUAL.
- 2 Remove & salvage sliding glass window and service counter assembly. Patch & repair adjacent surfaces to receive new finishes.
- 3 Remove & salvage observation window assembly. Cut opening beneath sill to floor. Construct bulkhead at 1'-0" a.f.f. Patch head, jamb, & floor to receive new finishes.
- 4 Patch & repair adjacent surfaces to receive new finishes, this area.
- 5 Prepare opening for new 3'-0"x7'-0" door.
- 6 Remove and reinstall exist. door & frame assembly in MEPS 150 door BVA. Install opening & patch adjacent surfaces to match exist.
- 7 Remove & salvage sliding glass window assembly. Patch and repair adjacent surfaces to receive new finishes, this area.
- 8 Remove exist. vinyl tread, riser, & landing tile. Patch & repair surfaces to receive new rubber tread, riser, freestride, & landings.

NOTE:
Remove all wood base tile and carpeting, entire floor. Patch wall & floor surfaces as required to receive new finishes.

LOWER LEVEL FLOOR PLAN

SALK COUNTY BUILDINGS
REEDSBURG, WI
HUMAN SERVICES BLDG RENOVATION

VIERBICHER
ARCHITECTS
400 VIKING DR. P.O. BOX 379 - REEDSBURG WI 53959 - 800-524-8488

DATE: 11/19/95 SCALE: As Noted

NO.	DATE	REVISIONS

REVISIONS

NO. DATE REVISIONS

2 11 AI

2 OF 11

FILE NO. 19-46253-00 T0203

JOB NO. 19-46253-00 T0203

DWG. NO. 11

DRAWN BY: mlw

CHECKED BY: mlw



LOWER LEVEL FLOOR PLAN

SCALE: 1/8" = 1'-0"